

FLEX – ALL – CLEAN

BLEND OF SPECIFIC DETERGENTS TO CLEAN FLEXO PLATES AND FLEXO MACHINE PARTS

A VOC FREE FAST-ACTING PHOTOPOLYMER PLATE CLEANER THAT SAFELY CLEANS ALL INKS AND VARNISHES.

Working Instructions

MANUAL USE

- Use pure, in case of resistant or dried ink.
- Let product act for few minutes, then remove residues of dirt and rinse.
- Can be used diluted up to 1:2 with water

Use for flexographic plate cleaning

- dilute product up to 50% in water
- Use product according to machine manufacturer instructions

Main characteristics

- Mild odor
- For manual use or automatic of clichet cleaning machines
- Low foam production
- Soluble in water
- Easy to rinse

Physical properties

Appearance	liquid
Density	0,95 gr/cc
VOC	FREE
Flash point	>100

Safetv

Read the safety specifications before using this product

Packing

20 lt metal can 200 lt metal drum 1000 lt tank

Storage

- Store at room temperature, in dry and well-aired place
- Keep far from heat and direct sunlight.
- Keep closed the containers.
- Storage time : 18 months from production date.

Information given in this sheet is considered to be reliable and is provided in good faith but without guarantee. Specifications subject to change without notice.

