



CLEANER MCB 85 PLUS

DETERGENT and ANTIOXIDANT SOLUTION for OFFSET NEGATIVE PLATES

Instructions for use

- **Product is ready-to-use**
- Apply it directly on plate surface, with contact time of 30 – 40 sec.
- Press sufficiently to clean not printing areas.
- Rinse with damping solution for 30 seconds.

For use with plates type TDG PLUS (Lucky Huaguang)

Physical characteristics :

Appearance	Amber coloured liquid
Density	1,030 Kg/lit
pH 25°C	7,00
Flash point	Not flammable

Safety

Read safety specifications before using this product.

Packing

20 litres cans

Storage

- Store at room temperature, in dry and well-aired place
- Keep far from heat and direct sunlight.
- Keep closed the containers.
- Storage time : 12 months from production date.

The information given in this sheet is to be considered reliable and is provided in good faith but without guarantee.
Specifications subject to change without notice.



imaf S.p.A.

Industria Materiali Fotochimici
Via Galvani, 2 - 20068 Peschiera Borromeo (MI)
Email: info@imaf.it - internet : www.imaf.it
Tel. ++39 0255302615 - ++39 0255302643