



US – 26 FLEXO

CONCENTRATED PRODUCT FOR ULTRASONIC CLEANING OF ANILOX CYLINDERS AND MECHANICAL PARTS OF PRINTING MACHINE

Working instructions

- Dilute the product from 1+25 up to 1+30 with water (for ex.: 10 lt of product with approx. 250-300 lt of water.)
- Mix well the solution.

Application

- Start up the ultrasounds device
- Let it act for the necessary time, for a perfect cleaning
- Switch off the device and rinse well with water

Precautions

- Avoid long contacts with aluminium.

Main characteristics

- Quick and thorough cleaning
- Suitable to all kinds of inks and varnishes
- Easy to be used

Physical properties

Appearance	Colourless liquid
Density	1,220 Kg/lt
pH 25°C	14,00
Flash point	100°C
Organic Volatile Compounds (VOC)	0%
Ink or varnish removal	High

Safety

Read the safety specifications before using this product.

Packing

10 litres cans

Storage

- Store at room temperature, in dry and well-aired place
- Keep far from heat and direct sunlight.
- Keep closed the containers.
- Storage time : 12 months from production date.

Information given in this sheet is considered to be reliable and is provided in good faith but without guarantee. Specifications subject to change without notice.



Industria Materiali Fotochimici
Via Galvani, 2 - 20068 Peschiera Borromeo (MI)
Email: info@imaf.it - internet : www.imaf.it
Tel. ++39 0255302615 - ++39 0255302643