



CORRETTORE FP

**CORRECTOR GEL FOR PRESENSITIZED PLATES
SUITABLE FOR ANALOGUE AND CTP THERMAL POSITIVE PLATE**

Instructions for use :

- Use a dry brush.
- Apply gel uniformly on the area to be corrected.
- Leave product act for 30-40" at least and wipe out with a wet sponge.
- Wash and gum.

Main characteristics

- Gel for correction of all presensitized positive plates, both analogue and CTP thermal ones.
- Excellent brushing allows a better spreading of product, assuring a perfect correction also on difficult areas, such as register marks at work edge without damaging the image screen.

Safety

Read safety specifications before using this product.

Packing

Bottle 100 ml

Storage

- Store at room temperature, in dry and well-aired place
- Storage time : 12 months from production date.

Waste

If possible collect and send them to an authorized waste management firm, in compliance with local and national regulations.

Properties

| | | |
|--------------------------|---------------|-----------|
| Chemical characteristics | Appearance | gel |
| | Colour | Pinkish |
| | Idromiscibile | Partially |

Too long contact on plates or too excessive wipe can damage the image.
The information given in this sheet is to be considered reliable and is provided in good faith but without guarantee.
Subject to change without notice.



imaf S.p.A.

Industria Materiali Fotochimici
Via Galvani, 2 - 20068 Peschiera Borromeo (MI)
Email: info@imaf.it - internet : www.imaf.it
Tel. ++39 0255302615 - ++39 0255302643