



OFFSET PENS

Correction pens for presensitized positive analogue and thermal plates

Working instructions

Wipe many times the pen tip on the not required printing area up to its complete dissolving, then wait for 30 - 60 seconds and wash with plenty of water .

Main characteristics

- It eliminates not required printing areas from plate surface after exposing and developing.
- Liquid contained in the pen deeply penetrates up to the grain porosity, being at the same time a solvent for the emulsion and making the aluminium hydrophilic.
- Suitable to correction of CTcP and CTP Plates, both single and double layer ones.

Safety

Read Safety Specifications before using product.

Packing and Storage

Available in 3 different tips : ultrafine, thin and thick

12 months after production date

Information given in this sheet has information and use instructions purpose.

Obtainable result is depending also on variables series, out of IMAF SpA control. Owing to this reason, information given in this document cannot cause legal complaint. Specifications are subject to change without notice.